



Quick Start Guide

PRECISION INDUCTION COOKTOP www.nuwavepic.com

Quick Start

- Press • Display: **425F** • Temperature: 425°F • Default 2 hours

Easy Pause

- Press once • Display: **425F** • Fan will turn off after 1 minute, Display will clear after 45 minutes.

Easy Stop

- Press twice • Display: **0** • Fan will turn off after 1 minute.

Easy Temperature Setting

- Press • Display: **SEAR** → • Press • Default 2 hours
- Press • Display: **175F**

Changing Cooking Temperature

ex) 250°F desired cooking temperature

- Press • Display: **275F** → • Press 3 times → • Press

Changing Cooking Time

ex) 3 hours and 45 minutes

- Press • Display: **00:00** → • Press 5 times • Display: **00:05** →
- Press • Display: **00:05** → • Press 4 times • Display: **00:45** →
- Press • Display: **00:45** → • Press 3 times • Display: **03:45**

Stage Cooking

ex) start cooking at High (425°F) for 5 minutes then Medium/Low (175°F) for 3 minutes

- Press → • Press • Display: **425F** → • Press • Display: **00:00**
- • Press 5 times • Display: **00:05** → • Press • Display: **175F**
- • Press • Display: **00:00** → • Press 3 times • Display: **00:03** → • Press

Delay

ex) Delay Cooking for 6 minutes then cook on High (425°F) for 3 minutes

- Press → • Press • Display: **00:00** → • Press 6 times • Display: **00:06** → • Press
- • Press • Display: **425F** → • Press → • Press 3 times • Display: **00:03** → • Press